




## KNOCK DOWN CABINET INSTRUCTIONS

Please review all parts in package. Each part has been labeled to help make assembly easy. No tools needed for assembly.

PART NUMBER	DESCRIPTION	QUANTITY
1	. LOWER LEFT SIDE	1
2	. LOWER RIGHT SIDE	1
3	. UPPER LEFT SIDE	1
4	. UPPER RIGHT SIDE	1
5	. LOWER BACK	1
6	. UPPER BACK	1
7	. SHELF	7
1	. 1/4 - 20 X 1/2 PAN HEAD SCREWS	22










Begin by locating Part #1 lower left side and Part #5 lower back. Align the machined holes making sure the **shelf support clips are facing up**. Locate the weld nuts on Part #1 lower left side, secure Part #5 lower back using 4 pan head screws.

Align Part #2 lower right side to Part #5 lower back using 4 pan head screws.

Place Part #7 shelf into the bottom row of shelf supports, by placing on an angle as shown, lift right side above support and push down. Make sure the shelf is secured in all six support clips.










Place second shelf onto the top row of shelf support clips. This should be done on an angle, same as the previous step.

Place the third shelf on the shelf support clips following the same process as step 4.


Place the fourth shelf on the shelf support clips following the same process as step 5.









The lower section is now complete. Move onto the assembly of the upper section.




Repeat the same process align Part #4 upper right side to Part #6 upper back using 4 pan head screws.












Place Part #7 shelf into the bottom row of shelf supports, by placing on an angle as shown, lift right side above support clips and push down. Make sure the shelf is secured in all six support clips.



Place the second Part #7 shelf on the shelf support clips following the same process as step 11.



Place the third Part #7 shelf on the shelf support clips following the same process as step 12.



COMPLETE!